longmaicm.com WhatsApp +86 181 6878 1275 info@longmaicm.com

What's in the Box

15 free items ship with every Longmai self-loading mixer truck — plus the cement hopper and hydraulic pressure washer fitted as standard.

> Every Longmai mixer leaves the factory with a full start-up kit: filters, hoses, fuses, grease nipples, a discharge chute and a dedicated cement hopper — everything needed for the first service interval and the first weeks of pouring. **Nothing is charged extra at delivery.** Spare-parts support continues for the life of the machine.

#	ITEM	QUANTITY	WHY IT MATTERS
1	Toolbox	1 pc	On-machine storage for the whole kit
2	Filter element (2036)	1 pc	First service spare
3	Engine oil filter — Yuchai	1 pc	First service spare
4	Diesel fuel filter — Yuchai	1 pc	First service spare
5	Throttle cable, 6 m	1 pc	Fast field replacement
6	Washing gun and hose set	1 set	Connects to the on-board hydraulic washer
7	External suction hose	1 pc	Draws water from a pond or canal into the tank
8	Water inlet switch	1 pc	Spare for the timed filling circuit
9	Wheel bolts (short)	2 sets	Roadside tyre changes
10	Grease nipples	20 pcs	Keeps every pivot point serviceable
11	Water check valve	1 pc	Prevents back-flow into the supply
12	Composite bushings	3 pcs	Wear parts for the loader linkage
13	Discharge chute	1 pc	Extends reach into formwork and trenches
14	Suction hose gasket	1 pc	Keeps the priming pump sealed
15	Fuses	15 pcs	Electrical spares
—	Cement hopper (fitted as standard)	1 pc	Pre-load cement while the bucket is loading — saves cycle time
—	Hydraulic pressure washer (fitted as standard)	1 set	Fitted on every unit — clean drum and chassis on site

Why this matters when you compare quotes

A lower headline price often hides a shorter included-parts list. Ask every supplier for their list in writing, then compare like for like — filters, hoses, consumables and the cement hopper are real money over the first year of operation. The cement hopper in particular saves time on every single batch: the operator loads cement while the bucket is still filling, so the machine never waits for the mixer to be hand-fed.

Fitted as standard on every unit

Hydraulic pressure washer

Clean the drum and chassis on site without a separate machine — critical for keeping mix off the drum between pours.

Cement hopper

Pre-load cement while the bucket fills. Cuts cycle time on every batch, all day long.

Timed water system

Self-priming pump plus dash timer with automatic shut-off — consistent water volume means a consistent mix.

Electronic weighing (optional)

Weighs every scoop to ±0.5% and prints a ticket, so each batch can be verified on paper.